

## SPEED HUMPS

### Installation Procedure (all models):

1. Using a chalk line, set out and position speed hump in their desired location. With a 10mm drill bit and impact drill, pilot drill the mounting holes for each module. (PHOTO'S 1 & 2).
2. Move the modules to one side and drill piloted holes with a 14mm drill bit 100mm deep. Clean dust from holes, insert the plastic Hilti plugs supplied and hammer flush with road surface. A little grease or oil on the screw threads will make them easier to tighten. (PHOTO'S 3 & 4).
3. Reposition the speed hump modules over holes and insert fixings making sure to use the washers supplied. (PHOTO 5).
4. Using an appropriate size socket wrench or impact driver tighten fixings. (PHOTO 6).
5. Clean the site to complete your installation. (PHOTO 7).
6. Go over completed installation and tighten all connections.

### Notes:

- To achieve long, straight lines use a string or chalk line.
- On completion check all fixings are tight.
- Always use personal protective equipment when using power tools.
- Always position humps at least 100mm clear of expansion gaps in the road surface. (PHOTO 7).



1.



2.



3.



4.



5.



6.



7.



8. Standard fixings supplied



### WHAT YOU WILL NEED

- Tape measure and string line.
- Impact drill and masonry bits.
- Socket wrench or impact driver.
- Can of lubricant.
- Hammer or mallet.
- Personal protective equipment.